



KICKOUT/DIVERTER FOR STUCCO

It is important to maintain a "shingle-fashion" concealed moisture barrier system. The "SHEET FLASHING" is installed by the carpenter behind and with the fascia board. This flashing provides a low cost back-up to manage incidental water intrusion. The building paper(s) or housewrap(s) must be installed under the sheet flashing below the kickout and over the sheet flashing at or above the kickout. A solid "Z bar" flashing (OPTIONAL UPGRADE) allows for re-roofing, casing bead is optional with Z flashing.

The SMA is an industry wide not-for-profit trade association dedicated to the promotion and education of the stucco industry. The SMA can provide no warranty, express or implied for the use of this detail. . This detail is not designed for a specific project and serves only as a guide detail for general use.